



Power Switch

New Generation, 1-port

PSE551



System Administrator's Guide



Power Switch


The PSE551 Power Switch is a power control unit with a built-in Web server, an Ethernet and a RS232 connection. It enables to control the power supply of a power outlet through an Ethernet connection. This unit offers additional IP device monitoring. It has a Real Time Clock to trigger scheduled actions and timestamp all events. Its serial interface enables to control the power outlet over a Terminal connection (KVM Switch, console server...) and to trigger a soft shutdown of a server with shutdown capabilities.

This device supports the HTTP, DHCP, Syslog, SNMP and SNTIP protocols.



This product carries the CE mark to indicate compliance with the European Directive on Electromagnetic Compatibility (2004/108/EEC). It has been tested to EN 60950-1, EN 55022, EN 55024

RoHS
COMPLIANT



CONTENTS

1. DESCRIPTION	2
1.1 Diagram	2
1.2 Package list	3
2. INSTALLATION	3
3. CONFIGURATION	5
3.1. Configuration through the LAN using the Finder program	5
3.2. Configuration through an RS232 Terminal connection	7
3.3. Configuration through the LAN using a standard Browser	8
3.3.1. General / IP configuration	9
3.3.2. General / System time	10
3.3.3. General / SNMP	11
3.3.4. General / Tools	12
3.3.5. Settings / Accounts	13
3.3.5.1 Settings / Accounts	13
3.3.5.2 Settings / Accounts / Hidden Page account	15
3.3.6. Settings / Groups N/A	17
3.3.7. Settings / Peripherals N/A	17
3.3.8. Settings / Rules	17
3.3.8.1. Settings / Rules - Schedule Rule	19
3.3.8.2. Settings / Rules - Timer Rule	21
3.3.8.3. Settings / Rules - Ping Monitoring Rule	23
3.3.8.4. Settings / Rules - Scan Monitoring Rule	25
3.3.9. Settings / Shutdowns	27
3.3.10. Misc / Control Panel	29
3.3.11. Misc / Rule Panel	30
3.3.12. Misc / Log	31
3.3.13. Misc / Log Settings	32
4. POWER OUTLET CONTROL	33
4.1. Power Outlet control with a browser	33
4.2. Power Outlet control with an RS232 Terminal connection	34
4.3. Power Outlet control using simple HTTP commands	35
5. APPENDIX	37
5.1. Ping and Scan Methods	37
5.2. Technical Data	38
5.3. Commonly used Ports	38
5.4. Syslog Messages: Severity Level Definitions	39

SAFETY INSTRUCTIONS: To be read before use!



NOTE

- The Power Switch devices can only be installed by qualified people with the following installation and use instructions. The manufacturer disclaims all responsibility in case of a bad utilization of the Power Switch devices and particularly any use with equipments that may cause personal injury or material damage.
- This equipment is designed to be installed on a dedicated circuit that must have a circuit breaker or fuse protection.
- The electrical power sockets used to plug the power cords of the Power Switch devices must be close to the Power Switch devices and easily accessible.
- Check that the power cords, plugs and sockets are in good condition.
- The Power Switch devices can only be connected to three-wire 230 VAC (50-60Hz) sockets.
- Always plug the Power Switch devices into properly grounded power sockets (two poles plus ground).
- Never exceed 10 Amp total load.
- The Power Switch devices are intended for indoor use only. Do NOT install them in an area where excessive moisture or heat is present.
- Always disconnect the power cord of the Power Switch device if you want to intervene on the Power Switch device or on the equipment powered from the Power Switch device.
- The power outlet of the Power Switch device is a not circuit breaker! If you want to intervene on equipments connected to a Power Switch device you must disconnect these equipments from the Power Switch device.
- Do NOT attempt to disassemble the Power Switch devices, they contain potentially hazardous voltages.
- The Power Switch devices contain no user serviceable parts and repairs are to be performed by factory trained service personnel only.
- Always use a shielded cable for the Ethernet connection.


1. DESCRIPTION

The **Power Switch 1-port** is a power control unit with a built-in Web server, an Ethernet and a RS232 connection. It enables to control the power supply of a power outlet through an Ethernet connection. This unit offers additional IP device monitoring. It has a Real Time Clock to trigger scheduled actions and timestamp all events. Its serial interface enables to control the power outlet over a Terminal connection (KVM Switch, console server...) and to trigger a soft shutdown of a server with shutdown capabilities.

The Power Switch 1-port supports the HTTP, DHCP, Syslog, SNMP and SNTTP protocols.

1.1 Diagram

The front panel of the **Power Switch 1-port**



S 1 2 3 4 (LEDs)

S Status

On = Power Switch 1-port software is loaded and functional
Off = power default

- 1 Red. Status of power outlet 1 (On/Off)
- 2 Red. Status of power outlet 2 (On/Off)
- 3 Red. Status of power outlet 3 (On/Off)
- 4 Red. Status of power outlet 4 (On/Off)

10/100 (RJ45 Connector)

Network connection 10/100 Mbits/sec

Link (LED)

Off = Network connection not detected

On = Network connection detected

Flashing = the device is sending or receiving data over this port

100 (LED)

Off = 10 Mbits/sec connection

On = 100 Mbits/sec connection

RS232 (SUB-D 9F Connector)

Serial port RS232 with DB-9 female connector

Pinout

2 = TxD

3 = RxD


5 = Gnd

A-xBus

The RJ45 connector is used for cascading up to 4 peripherals

Maximal TOTAL line length: 200 meters

The back of the **Power Switch 1-port**



1.2 Package list

The following items are included:

- 1 Powerwitch
- 1 power cable, 230 V / 10 Amp, length 1.80 Meters
- 1 RJ45 M/M cable, 2 Meters
- 1 serial cable SUB-D 9 points M/F, 1.80 Meters
- 1 quick installation guide
- 1 CD with User Guide, Quick Start Guide and Windows configuration program

2. INSTALLATION

Remark:

Make sure that the Power Switch 1-port is powered off.

Connection instructions

1. Use a shielded RJ45 network cable to connect your Power Switch 1-port to the network.
2. Use appropriated three-wire power cords (two poles plus ground) to connect your electrical devices to the Power Switch 1-port unit.
3. Plug the power cable into a grounded socket. The Status LED lights on to confirm that power is on.
4. You can now configure the Power Switch 1-port by following the indications of the chapter "Configuration of the Power Switch 1-port".

3. CONFIGURATION


To use the Power Switch 1-port on your network, you must first configure its network parameters. Ask your network administrator for the parameters to use.

There are three methods to configure the network parameters of the Power Switch 1-port:


3.1. Configuration through the LAN using the Finder program

It is the simplest and fastest configuration method if you use Windows as operating system. It allows to configure your Power Switch 1-port through your local network even if its network parameters are not compatible with those of your PC.

1. Start the BBFinder.exe program contained on the CD-ROM.
2. Open the File menu and choose **SCAN** (or click on the first left button in the tool bar) to discover the Power Switch 1-port connected on your LAN.



3. Open the File menu and choose **CONFIGURE** (or click on the second left button in the tool bar) to configure the network parameters.



This page enables to define all IP parameters of the Power Switch 1-port device and displays the version of the Firmware. The HTTP protocol is enabled and the Finder program is authorized at factory settings. **!!! To achieve the highest security level we suggest to disable the configuration using the Finder program after the first installation.**



DHCP:

Check this box if you want to obtain the IP address, the subnet mask and the default gateway for your Power Switch 1-port via DHCP.



Use of DHCP (Dynamic Host Configuration Protocol) requires a DHCP host to be set up on the network.

IP Address:

IP address of the Power Switch 1-port, default is 192.168.100.200.

Subnet Mask:

Subnet Mask of the Power Switch 1-port, default is 255.255.255.0.

Gateway:

Generally the address of your router, default is blank.

DNS 1:

Primary DNS (Domain Name Server), default is blank.

DNS 2:

Secondary DNS, default is blank.

Port Number:

Port number: default is 80 (HTTP).

Version:

Firmware version of the Power Switch 1-port

Finder authorized:

The Network parameters of the Power Switch 1-port can be configured through a Local Area Network using the provided Finder Program. It is a simple and fast configuration method if you use Windows as operating system.



!!! The Finder Program is enabled as default value. For security reasons we suggest to disable the Finder program after the first configuration.

3.2. Configuration through an RS232 Terminal connection

1. Use the provided RS232 cable to connect the Power Switch 1-port to an available serial port of your PC.
2. Run a Terminal program such as Windows HyperTerminal.
3. Configure the appropriate serial port @ 9.600, n, 8, 1 and no flow control.
4. On your computer, press <ENTER> until the menu appears on your screen.
5. Press the "M" on your keyboard and follow the menu to configure the network parameters of your Power Switch 1-port.

Special commands (type /? or /Help)

/initlog	Clears the log file
/initadminaccount	Restores default administrator password
/restorefactconf	Restores to factory default settings
/help /?	Displays this help

```
-----  
NETWORK INTERFACE PARAMETERS:  
  IP address on LAN is 192.168.100.200  
  LAN interface's subnet mask is 255.255.255.0  
  IP address of default gateway to other networks is 0.0.0.0  
  IP address of primary DNS server is 0.0.0.0  
  IP address of secondary DNS server is 0.0.0.0  
MISCELLANEOUS:  
  HTTP Port is 80  
  Finder program is enabled  
HARDWARE PARAMETERS:  
  MAC Address is 00.13.F6.01.3C.80  
-----
```

Configuration menu

3.3. Configuration through the LAN using a standard Browser

During the first installation, change temporarily the network settings of your PC according to the default network settings of the Power Switch 1-port.

Factory network settings of the Power Switch 1-port:

IP Address: **192.168.100.200** - Port: **80**

Gateway: **255.255.255.0**

1. Open your Web browser and type following IP address:
<http://192.168.100.200/sysadmin.htm>
2. Enter the administrator name and password (default for both = **admin**)
3. The home page appears, allowing you to configure all settings of your Power Switch 1-port.


The screenshot shows the web interface for the Black Box Network Services PSE 551. The page title is "IP Configuration" and it features a navigation menu with tabs for "General", "Settings", "Misc", and "Help". Below the navigation menu, there are sub-tabs for "IP Configuration", "System Time", "SNMP", and "Tools". The main content area displays the following configuration options:

DHCP Client enabled	<input type="checkbox"/>
IP Address	192.168.1.66
Subnet Mask	255.255.255.0
Default Gateway	192.168.1.2
Primary DNS Server	192.168.1.2
Secondary DNS Server	0.0.0.0
Finder Program enabled	<input checked="" type="checkbox"/>
HTTP Port	80

At the bottom of the page, there are three buttons: "LOGOUT", "DISCARD CHANGES", and "APPLY CHANGES".

3.3.1. General / IP configuration

This page enables you to define all the IP parameters of the Power Switch 1-port.



The screenshot shows the 'IP Configuration' page for a Black Box Network Services PSE 554 device. The page has a navigation bar with tabs for 'General', 'Settings', 'Misc', and 'Help'. Below this, there are sub-tabs for 'IP Configuration', 'System Time', 'SNMP', and 'Tools'. The 'IP Configuration' sub-tab is active, showing a form with the following fields:

- DHCP Client enabled:
- IP Address: 192.168.100.200
- Subnet Mask: 255.255.255.0
- Default Gateway: 0.0.0.0
- Primary DNS Server: 0.0.0.0
- Secondary DNS Server: 0.0.0.0
- Finder Program enabled:
- HTTP Port: 80

At the bottom of the page, there are three buttons: 'LOGOUT', 'DISCARD CHANGES', and 'APPLY CHANGES'.

DHCP Client enabled:

Check this box is you want to obtain the IP address, the subnet mask and the default gateway for your Power Switch 1-port via DHCP. Factory default setting for this option is disabled.

Use of DHCP (Dynamic Host Configuration Protocol) requires a DHCP host to be set up on the network.

IP Address:

IP address of the Power Switch 1-port, default is 192.168.100.200.

Subnet Mask:

Subnet Mask of the Power Switch 1-port, default is 255.255.255.0.

Default Gateway:

Generally the address of your router, default is blank.

Primary DNS Address:

Primary DNS (Domain Name Server), default is blank

Secondary DNS Address:

Secondary DNS, default is blank

Finder Program enabled:

The Network parameters of the Power Switch 1-port can also be configured through a Local Area Network using the provided Finder Program. It is a very simple and fast configuration method if you use Windows as operating system.

The Finder Program is enabled as default value.

!!!For security reasons we suggest to disable the Finder program after the first configuration.

HTTP Port:

Port number: default is 80.

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:

Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.

APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.

3.3.2. General / System time

The system time of the Power Switch 1-port is used to synchronize scheduling actions and to timestamp SNMP traps, Syslog information and internal logs. The system time can be set manually with the browser time of the connected computer or can be automatically synchronized with one or two NTP timeservers.

Current System Time:

This field shows the current system time of the Power Switch 1-port.

As the system time is displayed through the browser, a small difference (1 to 2 sec) can appear as compared to the exact hour. The system time is nevertheless correct.

Use Browser Time:

If you want to set the system time using the current Browser time of your PC, select this option and click on the "Set System Time" button.

Use NTP Server:

If you want to set the system time using an NTP timeserver, select this option, choose a refresh interval and enter the IP address of the timeserver you wish to use in the "Primary" field. The address of a second timeserver can be specified in the "Secondary" field. The secondary timeserver is optional and is used only if the primary timeserver is not available.

You can enter either the hostname (in that case you must have specified a DNS server on the IP configuration page) or the IP address of an NTP server.

NTP uses port 123/UDP.

Time Zone:

Set the time zone corresponding to your location. The system clock will subsequently show local time. Without setting this, the system clock will show UTC/GMT time. Setting a time zone is only relevant if you are synchronizing with an NTP server.

Daylight Saving Time:

If you want to set Daylight Saving dates, check this box and specify the date you want to use.

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:


Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.

APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.

3.3.3. General / SNMP

The Power Switch 1-port provides a built-in SNMP (Simple Network Management Protocol) agent, which enables you to manage the Power Switch 1-port through SNMP-based network management systems. The Power Switch 1-port MIB file enables to remotely read out the status of all power outlets and the values of all sensors (temperature, humidity, ambient light). It also enables to control individually all power outlets and all groups of power outlets. The MIB file is stored on the Power Switch 1-port and can be downloaded from the General / Tools Page.



SNMP enabled:

Check this box if you want to enable the SNMP protocol.

Contact:

In this field, enter the name you want to give to the Contact field. The name can be from 1 to 64 characters long, and can contain alphanumeric characters. Default name is "contact".

Name:

In this field, enter the name you want to give to the Name field. The name can be from 1 to 64 characters long, and can contain alphanumeric characters. Default name is "name".

Location:

In this field, enter the name you want to give to the Location field. The name can be from 1 to 64 characters long, and can contain alphanumeric characters. Default name is "location".

Read Community:

In this field, enter the name you want to give to the Read Community field. The name can be from 1 to 64 characters long, and can contain alphanumeric characters. Default name is "public".

Write Community:

Check this box if you want to be able to control the power outlets through a MIB browser. In the following field, enter the name you want to give to the Write Community. The name can be from 1 to 64 characters long, and can contain alphanumeric characters. Default name is "private".

Trap Community:

Check this box if you want to configure the Power Switch 1-port SNMP agent to send traps to a community. In the following field, enter the name you want to give to the Trap Community. The name can be from 1 to 64 characters long, and can contain alphanumeric characters. Default name is "trap".

Trap Destination 1:

Check this box and enter the primary SNMP Server address the traps will be sent to.

Trap Destination 2:

Check this box and enter the secondary SNMP Server address the traps will be sent to.

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:

Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.


APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.

3.3.4. General / Tools

This page enables you to:

- download and save the current settings of your Power Switch 1-port on your PC,
- upload an existing configuration file to your Power Switch 1-port,
- restore the factory settings,
- download the Power Switch 1-port MIB file on your PC.

**Save:**

Click this button to save the current system settings onto your local hard drive.

Load:

Click this button and select a settings file you want to download to the Power Switch 1-port.

Restore:

Click this button if you want to restore the factory default settings.

Save MIB:

Click this button if you want to download the Power Switch 1-port MIB file onto your local hard drive.


LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.


3.3.5. Settings / Accounts

3.3.5.1 Settings / Accounts

This page is used to create, activate, deactivate, modify and delete up to 40 accounts.



- To activate or deactivate an account, check or uncheck the corresponding checkbox.
- To modify an account, click on "Edit" next to the corresponding account.
- To delete an existing account, click on "Delete" next to the corresponding account.
- To create an account, click on "Add a New Account" on the right side of the page.
A new page appears, allowing you to set all the parameters of the account.



User Name:

In this field, enter the name you want to give to the user. The name can be from 1 to 32 characters long, and can contain alphanumeric characters.



Do not use quotes or special characters in labels!

Password:

In this field, enter the password you want to give to the user. The password can be from 4 to 32 characters long, and can contain alphanumeric characters.

Confirm Password:

In this field, enter the password again.

IP Address Control:

Check this checkbox and specify an IP address or a range of IP address if you want to restrict the access of this account.

Device:

In this drop-down list, choose a device from which you want to add Inputs or Outputs to the current account.

Inputs/Outputs:

This field is used to add/remove Inputs to/from the current account.

To add Inputs to the current account, press the Ctrl key and click on the Inputs/Outputs of the device selected in the previous field. The selected Inputs are marked dark blue and their IDs are listed at the right side of the Input/Output field.

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:


Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.

APPLY CHANGES:


Click "Apply Changes" at the bottom of the page to save changes.

3.3.5.2 Settings / Accounts / Hidden Page account

This account is intended for developers who want to implement the power outlet control in own programs. If activated, they can access to a special page named hidden.htm and control individually the power outlets using simple commands.



- To activate or deactivate this account, check or uncheck the corresponding checkbox.
- To modify the Hidden page account, click on "Edit" next to the corresponding account. A new page appears, allowing you to set all the parameters of the account.



Activated

This check box must be checked to activate the Hidden Page Account. It enables to deactivate temporarily this account while keeping all its settings for a later use. The Hidden Page Account cannot be deleted.

User Name

In this field, enter the name you want to give to the Hidden Page Account.

The user name can be up to 32 characters long and contain alphanumeric characters.

Do not use quotes or special characters in labels!

Password

In this field, enter the password you want to give to the Hidden Page Account.

The password can be up to 32 characters long and contain alphanumeric characters.

Confirm Password

In this field, enter the password again for confirmation.

IP Address Control

Network security can be increased by IP address filtering. Check this checkbox and specify an IP address or a range of IP addresses which has the right to access to the Hidden Page Account.



Device

In this drop-down list, choose the device from which one you want to add an Input to the current account.

Inputs/Outputs

- This field is used to add/remove Inputs to/from the current account.
- To add an Input to the current account, select the Input you want to add in the left field and click on the Arrow button, the selected Input will then appear in the right field.
- To remove an Input from the current account, select the Input / Output you want to remove in the right field and click on the Arrow button, the selected Input will then appear in the left field.

Accessing to the Hidden Page Account

To be able to access to the Hidden Page, you must have configured the Hidden Page Account and activated it. For the first tests, simply check the Activated check box, start your browser and type into your browser's address bar the IP address of your power switch followed by the name of the hidden page.

Example: if the IP address of your Power Switch is 192.168.100.200, type in:

<http://192.168.100.201/hidden.htm> followed by <ENTER>.

Your Web browser will now display:

```
Hidden Page
21 Dec 2010 01:50:03
Version: 2.1.0.0
```

Controlling the Power Outlet

The selected Power Outlet can be controlled over the Hidden Page. To select the Power Outlet, go to the "Settings/Accounts" page and edit the Hidden Page Account.

Example: if you have selected the power Outlet and the IP address of your Power Switch is 192.168.100.200, type in:

<http://192.168.100.201/hidden.htm> followed by <ENTER>.

Your Web browser will now display:

```
Hidden Page
21 Dec 2010 02:29:01
Version: 2.1.0.0
M0:01=On
```

The Power Outlet supports 3 commands: On, Off and Restart using following syntax:

M0:0x=[ON], [OFF], [RESTART]

M0: ID of your Power Switch

Ox: Outlet number of your Power Switch

ON: ON command

OFF: OFF command

RESTART: Restart command

The first command must be preceded by a "?"

Commands can be concatenated using the character "&"


Commands can be specified in upper case, lower case or mixed case

3.3.6. Settings / Groups N/A

3.3.7. Settings / Peripherals N/A

3.3.8. Settings / Rules


Rules are used to control actions according to a specific event. For example, you can define rules to switch the power outlet OFF from Friday evening to Monday morning.



- To remove an existing rule, click on "Delete" of the corresponding rule.
- To modify a rule, click on "Edit" of the corresponding rule.

This page is used to create, modify and delete rules.

- To add a new rule, click on "Add a New Rule" on the right side of the page. A new page appears, allowing you to set all the parameters of the rule.



A total of 32 rules can be created and there are 4 different types of rules:

1. Schedule Rule:

This rule is used to trigger user-specified actions according to a defined time table.

This rule can be used to:

- execute **once** defined actions at specified time and weekday(s). In this case you must only specify the start time and the weekday(s),
- execute **repeatedly** defined actions during a given time. In this case you must specify the start time, the interval on which the rule has to be repeated and the end time.

Examples:

- The rule can be used to restart a power outlet at regular interval during a given time.
- The rule can be used to send a Syslog message at regular interval during a given time.

2. Timer Rule:

This rule can be used to trigger user-specified actions according to a defined time table.

This rule can be used to switch On or Off a power outlet at specified time and weekday(s) for a specified time. You must define the start time, the weekday(s) and the stop time.

Example:

- The rule can be used to switch On a device every Monday and Friday from 8:00 AM (Start Time) and switch it automatically off every Monday and Friday at 05:00 PM (Stop Time)

3. Ping Monitoring Rule:

This rule is used to control actions according to the response to a Ping command.

This rule can be used to check if a computer or any IP device is connected to the network. If the host doesn't reply, the Power Switch can automatically restart the powered device.


4. Scan Monitoring Rule:

This rule is used to control actions according to the response to a Scan command.

This rule can be used to check if a specific protocol is available on a. If the connection is not possible, Power Switch can automatically restart the powered device.

3.3.8.1. Settings / Rules - Schedule Rule

This rule can be used to trigger user-specified actions according to a defined time table. The schedule rule is weekday based and the administrator can declare, for each weekday, a start time, an end time and after what time the rule should be repeated.



Activated

This check box must be checked to activate the Rule and enables to deactivate temporarily a rule while keeping all its settings for a later use.

Rule ID:

The Power Switch automatically creates an ID Code to clearly identify each rule. All the ID Codes used to identify rules start with the letter "R" followed by a number from 1 to 32. If you delete a rule in the middle of the Rule list, the number of this rule will only be used again if no other rule is available.

Rule Name:

In this field, enter the name you want to give to the rule. The name can be from 1 to 32 characters long, and can contain alphanumeric characters.

Do not use quotes or special characters in labels!

Rule Color:

In this field, select one of the 48 standard colours you want to use to highlight the rule when executed. To use own colours, just type in the Hex value of the colour you want. The Rule highlighting allows to quickly identify the triggered rule when displayed in the Rule Panel page or in a special user's page.

Rule Type:

In this drop-down list, choose Schedule Rule then configure the event and the actions to perform.

Configuring the Event

Schedule Action:

Here you can define the time when the rule has to be executed. In the Drop-Down lists choose the time and below, check one or more day boxes.

Start Time

Defines what time the rule starts.

Repeat Time

Defines the time period in which the rule repeats.

Repeat Time cannot be set to zero.

Stop Time

Defines what time the rule ends.

Note

- **End Time must be greater than or equal to Start Time.**
- **If the rule has to be executed only once at the selected weekday, enter the same value for Start Time and End Time.**
- **If the rule has to be executed 24 hours at the selected weekday, Start Time must be 1 minute later than EndTime.**

Applicable weekday

Defines which day(s) the rule has to be executed.

Type of Action

For the Event defined above, you can choose and configure following actions:

Set Power Outlet:

Check this box and in the corresponding drop-down list, select the power outlet the rule will apply to. In the next corresponding drop-down list, choose the action to execute. The power outlet can be switched On/Off and restarted. If you choose "restart" you will also be able to define a restart delay between 0 and 65535 seconds.

- If you choose 0 second, the delay will be the delay defined in the Power Switch power outlet settings.
- If you choose a delay different from 0, the delay will replace the delay defined in the Power Switch power outlets settings.

Send Syslog Message:

Note

This type of action can be configured only if you have already created at least one destination Syslog Server (Misc/Log Settings Tab).

Check this box if you want to send a message to a Syslog server. In the following drop-down lists choose the facility and the severity of the message to send. The address of the Syslog server has to be defined in the "Log Settings Page".

Send Trap Message:

Note

This type of action can be configured only if you have already specified at least a destination SNMP Server (General/SNMP Tab).

Check this/these box(es) and specify one or two SNMP addresses in the corresponding field if you want to send SNMP messages to one or two SNMP Servers.

Syslog / Trap Message:

Note

This field can be used only if you have already specified at least one destination Syslog Server (Misc/Log Settings Page) or one destination SNMP Server (General/SNMP Page).

Up to 255 characters may be entered in this free text field. The text will appear in the Syslog and the Trap. The message can be completed with the status of an input (a power supply or door contact for example) or the value of a sensor (a temperature sensor for example). For this, simply enter, between two percent characters, the ID of the corresponding input device (for details see § 5.1 Sending status and values using rules).

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:

Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.

APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.

3.3.8.2. Settings / Rules - Timer Rule

This rule can be used to trigger some actions according to a defined time table. For instance, you could create a rule to switch OFF a Power Outlet every Friday at 6 PM and create another rule to switch the Power Outlets ON again every Monday at 8 AM.

The screenshot displays the 'Add a New Monitoring Rule' configuration page. The top navigation bar includes 'General', 'Settings', 'Misc', and 'Help'. Below this, a secondary bar shows 'Accounts', 'Groups', 'Peripherals', 'Rules', and 'Shutdowns'. The main content area is titled 'Add a New Monitoring Rule' and contains the following fields and options:

- Activated:** A checkbox that is currently unchecked.
- Rule ID:** A text input field containing 'R1'.
- Rule Name:** An empty text input field.
- Rule Color:** A color selection field showing a yellow swatch.
- Rule Type:** A dropdown menu set to 'Timer Rule'.
- Timer Action:**
 - Start Time:** Two dropdown menus for 'Hour' and 'Minute', both set to '00'.
 - Stop Time:** Two dropdown menus for 'Hour' and 'Minute', both set to '00'.
 - Applicable Weekday:** A row of checkboxes for Sun, Mon, Tue, Wed, Thu, Fri, and Sat, all of which are unchecked.
- Type of Action:** A list of actions with checkboxes:
 - Set Power Outlet: Includes dropdowns for 'Set Power Outlet to On/Off' and 'to'.
 - Send Syslog Message: Includes dropdowns for 'Send Syslog Message' and 'to'.
 - Send Trap Message: Includes dropdowns for 'Send Trap Message' and 'to'.
 - Syslog/Trap Message: Includes a dropdown for 'Syslog/Trap Message' and a text input for 'to'.

At the bottom of the form, there are three buttons: 'LOGOUT', 'DISCARD CHANGES', and 'APPLY CHANGES'.

Activated

This check box must be checked to activate the rule. It enables to deactivate temporarily a rule while keeping all its settings for a later use.

Rule ID

The Power Switch automatically creates an ID Code to clearly identify each rule. These codes start with the letter "R" followed by a number.

Rule Name

In this field, enter the name you want to give to the rule. The name can be from 1 to 32 characters long, and can contain alphanumeric characters.

Do not use quotes or special characters in labels!

Rule Color:

In this field, select one of the 48 standard colours you want to use to highlight the rule when executed. To use own colours, just type in the Hex value of the colour you want. The Rule highlighting allows to quickly identify the triggered rule when displayed in the Rule Panel page or in a special user's page.

Rule Type

In this Drop-Down list, choose Schedule Rule.

Rules are used to control actions according to a specific event. To create a rule, you will first have to configure the chosen event and then to choose the actions to perform.

Configuring the Event

Timer Action

Start Time

Defines what time the rule starts.

Stop Time

Defines what time the rule ends.

Applicable weekday

Defines which day(s) the rule has to be executed.

Type of Action

For the Event defined above, you can choose and configure following actions:

Set Power Outlet:

Check this box and in the corresponding drop-down list, select the power outlet the rule will apply to. In the next corresponding drop-down list, choose the action to execute. Each power outlet can be switched On/Off and restarted. If you choose "restart" you will also be able to define a restart delay between 0 and 65535 seconds.

- If you choose 0 second, the delay will be the delay defined in the Power Switch power outlets settings.
- If you choose a delay different from 0, the delay will replace the delay defined in the Power Switch power outlets settings.

Send Syslog Message:

 This type of action can be configured only if you have already created at least one destination Syslog Server (Misc/Log Settings Tab).

Check this box if you want to send a message to a Syslog server. In the following drop-down lists choose the facility and the severity of the message to send. The address of the Syslog server has to be defined in the "Log Settings Page".

Send Trap Message:

 This type of action can be configured only if you have already specified at least a destination SNMP Server (General/SNMP Tab).

Check this/these box(es) and specify one or two SNMP addresses in the corresponding field if you want to send SNMP messages to one or two SNMP Servers.

Syslog / Trap Message:

 This field can be used only if you have already specified at least one destination Syslog Server (Misc/Log Settings Page) or one destination SNMP Server (General/SNMP Page).

Up to 255 characters may be entered in this free text field. The text will appear in the Syslog and theTrap. The message can be completed with the status of an input (a power supply or door contact for example) or the value of a sensor (a temperature sensor for example). For this, simply enter, between two percent characters, the ID of the corresponding input device (for details see § 5.1 Sending status and values using rules).

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:

Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.

APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.

3.3.8.3. Settings / Rules - Ping Monitoring Rule

This rule can be used to check if a computer or any IP device is connected to the network. It sends ping packets and listens for replies from the specific host. If the host doesn't reply, the Power Switch can automatically switch the powered device off and after a specified delay, switch it again on (for details see Ping & Scan Method).

Activated

This check box must be checked to activate the Rule and enables to deactivate temporarily a rule while keeping all its settings for a later use.

Rule ID:

The Power Switch automatically creates an ID Code to clearly identify each rule. All the ID Codes used to identify rules start with the letter "R" followed by a number from 1 to 32. If you delete a rule in the middle of the Rule list, the number of this rule will only be used again if no other rule is available.

Rule Name:

In this field, enter the name you want to give to the rule. The name can be from 1 to 32 characters long, and can contain alphanumeric characters.

Do not use quotes or special characters in labels!

Rule Color:

In this field, select one of the 48 standard colours you want to use to highlight the rule when executed. To use own colours, just type in the Hex value of the colour you want. The Rule highlighting allows to quickly identify the triggered rule when displayed in the Rule Panel page or in a special users page.

Rule Type:

In this drop-down list, choose Ping Monitoring Rule then configure the event and the actions to perform.

Configuring the Event

Monitored device address:

In this field enter the IP address of the IP device that you want to monitor using the Ping command.

Wait Time for Answer:

In this field, define the delay in seconds for the Answer Timeout. The delay can be set between 1 and 10 seconds.

Interval between Requests:

In this field, define the delay in seconds between ping commands sent to the IP device to monitor. The delay can set between 30 and 65535 seconds.

Number of unsuccessful Requests before Action:

In this field, define the number of Ping commands to be sent to the IP device before executing the actions. The number can be set between 1 and 65535 seconds.

Delay before First Request after Action:

In this field, define the time in seconds before restarting the monitoring after the reboot action. The delay can be set between 30 and 65535 seconds.

Maximum Number of Actions

In this field, define the maximum number of actions. The number can be set between 0 and 255.

Type of Actions:

For the Event defined above, you can choose and configure following actions:

Set Power Outlet:

Check this box and in the corresponding drop-down list, select the power outlet the rule will apply to. In the next corresponding drop-down list, choose the action to execute. Each power outlet can be switched On/Off and restarted. If you choose "restart" you will also be able to define a restart delay between 0 and 65535 seconds.

- If you choose 0 second, the delay will be the delay defined in the Power Switch power outlets settings.
- If you choose a delay different from 0, the delay will replace the delay defined in the Power Switch power outlets settings.

Send Syslog Message:

This type of action appears and can be configured only if you have already created at least one destination Syslog Server (Misc/Log Settings Tab).

Check this box if you want to send a message to a Syslog server. In the following drop-down lists choose the facility and the severity of the message to send. The address of the Syslog server has to be defined in the "Log Settings Page".

Send Trap Message

This type of action appears and can be configured only if you have already specified at least a destination SNMP Server (General/SNMP Tab).

Check this/these box(es) and specify one or two SNMP addresses in the corresponding field if you want to send SNMP messages to one or two SNMP Servers.

Syslog / Trap Message

This field can be used only if you have already configured at least one destination Syslog Server (Misc/Log Settings Page).

Up to 255 characters may be entered in this free text field. The text will appear in the Syslog and the Trap.

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:

Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.

APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.

3.3.8.4. Settings / Rules - Scan Monitoring Rule

This rule can be used to check if a specific protocol is available on a server (for example HTTP, FTP, Telnet, POP...). If the connection is possible, Power Switch knows that a server program is running there. If the connection is not possible, the Power Switch can automatically switch the powered device off and, after a specified delay, switch it again on (for details see Ping & Scan Method).

The screenshot shows the 'Add a New Monitoring Rule' configuration page. The 'Activated' checkbox is unchecked. The 'Rule ID' is 'R1'. The 'Rule Name' is empty. The 'Rule Color' is set to yellow. The 'Rule Type' is 'Scan Monitoring Rule'. The 'Monitored Device Address' and 'Port to scan' fields are empty. The 'Wait Time for Answer' is 1 sec, 'Interval between Requests' is 30 sec, 'Number of unsuccessful Requests before Action' is 1, 'Delay before First Request after Action' is 30 sec, and 'Maximum Number of Actions' is 0. The 'Type of Action' section has three checkboxes: 'Set Power Outlet' (unchecked), 'Send Syslog Message' (unchecked), and 'Send Trap Message' (unchecked). Each checkbox has associated dropdown menus and input fields. At the bottom, there are buttons for 'LOGOUT', 'DISCARD CHANGES', and 'APPLY CHANGES'.

Activated

This check box must be checked to activate the Rule and enables to deactivate temporarily a rule while keeping all its settings for a later use.

Rule ID:

The Power Switch automatically creates an ID Code to clearly identify each rule. All the ID Codes used to identify rules start with the letter "R" followed by a number from 1 to 32. If you delete a rule in the middle of the Rule list, the number of this rule will only be used again if no other rule is available.

Rule Name:

In this field, enter the name you want to give to the rule. The name can be from 1 to 32 characters long, and can contain alphanumeric characters.

Do not use quotes or special characters in labels!

Rule Color:

In this field, select one of the 48 standard colours you want to use to highlight the rule when executed. To use own colours, just type in the Hex value of the colour you want. The Rule highlighting allows to quickly identify the triggered rule when displayed in the Rule Panel page or in a special users page.

Rule Type:

In this drop-down list, choose Scan Monitoring Rule then configure the event and the actions to perform.

Configuring the Event

Monitored Device Address:

In this field, enter the IP address of the IP device that you want to monitor using the Scan command. In the "Port to scan" field, enter the port number you want to monitor. The value can be set between 1 and 65535.

Wait Time for Answer:

In this field, define the delay in seconds for the Answer Timeout. The delay can be set between 1 and 10 seconds.

Interval between Requests:

In this field, define the delay between the scan commands sent to the IP device. The delay can be set between 30 and 65535 seconds.

Number of unsuccessful Requests before Action:

In this field, define the number of Port scanning commands to be sent to the IP device before executing the actions.

The number can be set between 1 and 65535 seconds.

Delay before First Request after Action:

In this field, define the time in seconds before restarting the monitoring after the reboot action. The delay can be set between 30 and 65535 seconds.

Maximum Number of Actions

In this field, define the maximum number of actions.

The number can be set between 0 and 255.

Configuring the Actions

For the Event defined above, you can choose and configure following actions:

Set Power Outlet:

Check this box and in the corresponding drop-down list, choose the power outlet the rule will apply to. In the next corresponding drop-down list, choose the action to execute. Each power outlet can be switched On/Off and restarted. If you choose "restart" you will also be able to define a restart delay between 0 and 65535 seconds.

- If you choose 0 second, the delay will be the delay defined in the Power Switch power outlets settings.
- If you choose a delay different from 0, the delay will replace the delay defined in the Power Switch power outlets settings.

Send Syslog Message:

This type of action can be configured only if you have already created at least one destination Syslog Server (Misc/Log Settings Tab).

Check this box if you want to send a message to a Syslog server. In the following drop-down lists choose the facility and the severity of the message to send. The address of the Syslog server has to be defined in the "Log Settings Page".

Send Trap Message:

This type of action can be configured only if you have already specified at least a destination SNMP Server (General/SNMP Tab).

Check this/these box(es) and specify one or two SNMP addresses in the corresponding field if you want to send SNMP messages to one or two SNMP Servers.

Syslog / Trap Message:

This field can only be used if you have already specified at least one destination Syslog Server (Misc/Log Settings Page) or one destination SNMP Server (General/SNMP Page).

Up to 255 characters may be entered in this free text field. The text will appear in the Syslog and the Trap.

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:


Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.

APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.

3.3.9. Settings / Shutdowns


This power switch supports shutdown facilities of 1 server via its Serial RS232 interface.



- To remove an existing Shutdown association, click on "Delete" of the corresponding rule.
- To modify a Shutdown rule, click on "Edit" of the corresponding rule.

This page is used to create, modify and delete a Shutdown Association. Click on "Add a New Shutdown" on the right side of the page.

A new page appears, allowing you to set all the parameters of the rule.



Activated

This check box must be checked to activate the Shutdown Rule and enables to deactivate temporarily a rule while keeping all its settings for a later use.

Shutdown Association ID

The Power Switch automatically creates ID codes to clearly identify each rule. The codes used to identify Shutdown Rules start with the letters "SDA" followed by a number.

Shutdown Association Name

In this field, enter the name you want to give to the rule. The name can be from 1 to 32 characters long, and can contain alphanumeric characters.

Do not use quotes or special characters in labels!

Delay after Shutdown before continue

In this field, specify a delay after which the associated power outlet will be switch to off.

Shutdown Device

In this Drop-Down list, choose the device which will be used to trigger the Shutdown action. If the Power Switch is used as stand-alone unit, this Drop-Down list will only show the Power Switch itself.

Shutdown Outputs

In this field, choose the output which will be used to trigger the Shutdown.

- To select an output, select the output you want to add in the left field and click on the Arrow button, the output will then appear in the right field.
- To remove the selected output, select this output in the right field and click on the Arrow button, the output will then appear in the left field.

Device

In this Drop-Down list, choose the device of which the power outlet will be used to trigger the Shutdown action. If the Power Switch is used as stand-alone unit, this Drop-Down list will only show the Power Switch itself.

Power Outlets

In this field, choose the Power Outlet will be used to trigger the Shutdown.

- To select a Power Outlet, select the Power outlet you want to add in the left field and click on the Arrow button, the Power Outlet will then appear in the right field.
- To remove the selected Power Outlet, select this Power Outlet in the right field and click on the Arrow button, the Power Outlet will then appear in the left field.

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:

Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.

APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.


3.3.10. Misc / Control Panel

This page is very helpful for the administrator because it gives a complete overview. At a glance, the administrator can check the status of the power outlet.




3.3.11. Misc / Rule Panel

This page shows all the rules the administrator has created and activated. The rules which have been executed can also be highlighted in different colours according to the emergency of the action. The highlight colours can be customized during the creation of the rule (Settings/Rules Page).



For supervision purpose, the administrator can create special accounts which display only some specific rules. In the example below, the user Bill has the possibility to supervise 2 rules and to see on a glance the rules which have been triggered.




The page is automatically refreshed every 10 seconds.

Unlike a standard session, the web server of the Power Switch won't automatically close this kind of session. Opening many sessions of this affects the performances of the web server.


3.3.12. Misc / Log

The log file keeps a running log of events and activities occurring on the device. The logs are automatically cleared when the device is rebooted. The file will display 10 recent logs.



3.3.13. Misc / Log Settings

This page allows you to configure the logs. The Log file is used by the system to record actions, warnings, errors and problems. It is often quite useful to discover the causes of tricky problems. The messages recorded in the log file and sent as copy to a Syslog server are classified into 8 severity levels (Emergency, Alert, Critical, Error, Warning, Notice, Informational and Debug).



Primary Syslog Server:

Server Address" and enter the address of the Syslog Server you wish to use.

You can enter either the hostname or the IP address of a Syslog server. The Syslog uses port 443/UDP. If you want to enable the Power Switch to send messages to a Syslog Server, check the box "Syslog Note: if you use a hostname, it is important that the system can resolve the hostname locally and so you need to configure a Default Gateway and at least one DNS Server on the Network Settings Page (General/IP Configuration page).

Secondary Syslog Server:

In this field you can define the IP Address of a secondary Syslog Server. You can enter either the hostname or the IP address of a Syslog server.

LOGOUT:

Click "Logout" at the bottom of the page to exit the session without saving changes.

DISCARD CHANGES:

Click "Discard Changes" at the bottom of the page to discard all the changes you have made on this page.


APPLY CHANGES:

Click "Apply Changes" at the bottom of the page to save changes.

4. POWER OUTLET CONTROL

4.1. Power Outlet control with a browser

1. Start your Web browser and type the IP address of your Power Switch. The browser displays the authentication dialog box.
2. Enter a user name and its corresponding password. The status of the Power Switch is displayed.



3. In the drop-down list, choose the power control unit you want to control or the rule for which you want to know the status.


The ON button allows you to switch ON the power outlet.

The OFF button allows you to switch OFF the power outlet.

The RESTART button allows you to switch OFF the power outlet. The power outlet will then be automatically switched ON after the delay defined by the administrator (see Settings / power outlet Page).

If you log in as system administrator, you will be able to control the power outlet and display the status of the rules.

If you log in as a user (Power Switch handles up to 40 accounts), you will be able to control the power outlet and display the status the rules for which you have the rights.



4.2. Power Outlet control with an RS232 Terminal connection

The power outlet of the Power Switch PSE551 can be controlled using a simple ASCII protocol over an RS232 serial connection.

1. Use the provided RS232 serial cable to connect the Power Switch to an available serial port of your PC. Otherwise, use a USB/RS232 converter
2. Run a terminal program on your PC
3. Configure the appropriate serial port of your PC with following settings:
9.600 bauds, 8 bits, no parity, 1 stop bit and no flow control.

On your computer, press <ENTER> until the configuration menu appears on your screen.

Syntax of the command line:

**The command line must begin with a slash character (/).
This character will not appear on your PC, so do not type it twice.**

```
/P01=1 <ENTER>  switch power outlet ON  
/P01=0 <ENTER>  switch power outlet OFF  
/P01=r <ENTER>  restart power outlet  
/P01=t <ENTER>  toggle power outlet
```




- **The Power Switch PSE551 accepts lower-case and upper-case commands.**
- **The Power Switch PSE551 sends an echo for each received character.**


4.3. Power Outlet control using simple HTTP commands

Developers who want to implement the power outlet control in own programs can access to a special page named hidden.htm and control individually the power outlets using simple commands.

To configure the Hidden Page Account, go to Settings / Accounts.



- To activate or deactivate this account, check or uncheck the corresponding checkbox.
- To modify the Hidden page account, click on "Edit" next to the corresponding account. A new page appears, allowing you to set all the parameters of the account.



Activated

This check box must be checked to activate the Hidden Page Account. It enables to deactivate temporarily this account while keeping all its settings for a later use. The Hidden Page Account cannot be deleted.

User Name

In this field, enter the name you want to give to the Hidden Page Account.

The user name can be up to 32 characters long and contain alphanumeric characters.

Do not use quotes or special characters in labels!

Password

In this field, enter the password you want to give to the Hidden Page Account.

The password can be up to 32 characters long and contain alphanumeric characters.

Confirm Password

In this field, enter the password again for confirmation.

IP Address Control

Network security can be increased by IP address filtering. Check this checkbox and specify an IP address or a range of IP addresses which has the right to access to the Hidden Page Account.



Device

In this drop-down list, choose the device from which one you want to add Inputs or Outputs to the current account.

Inputs/Outputs

- This field is used to add/remove Inputs or Outputs to/from the current account.
- To add an Input or Output to the current account, select the Input / Output you want to add in the left field and click on the Arrow button, the selected Input / Output will then appear in the right field.
- To remove an Input or Output from the current account, select the Input / Output you want to remove in the right field and click on the Arrow button, the selected Input / Output will then appear in the left field.

Accessing to the Hidden Page Account

To be able to access to the Hidden Page, you must have configured the Hidden Page Account and activated it. For the first tests, simply check the Activated check box, start your browser and type into your browser's address bar the IP address of your power switch followed by the name of the hidden page.

Example: if the IP address of your Power Switch is 192.168.100.200, type in:
<http://192.168.100.201/hidden.htm> followed by <ENTER>.

Your Web browser will now display:

```
Hidden Page
21 Dec 2010 01:50:03
Version: 2.1.0.0
```

Controlling Power Outlets

Only Power Outlets which have been selected can be controlled over the Hidden Page. To select Power Outlets, go to the "Settings/Accounts" page and edit the Hidden Page Account. In the Inputs/Outputs field, selected the Power Outlets you want to control and click on the Arrow button next to the Inputs/Outputs field. The selected Power outlets appear in the right field, click on Apply Change to validate the configuration.

Example: if you have selected the power Outlet and the IP address of your Power Switch is 192.168.100.200, type in:
<http://192.168.100.201/hidden.htm> followed by <ENTER>.

Your Web browser will now display:

```
Hidden Page
21 Dec 2010 02:29:01
Version: 2.1.0.0
M0:01=On
```

The Power Outlet supports 3 commands: On, Off and Restart using following syntax:
M0:0x=[ON], [OFF], [RESTART]

```
M0: ID of your Power Switch
Ox: Outlet number of your Power Switch
ON: ON command
OFF: OFF command
RESTART: Restart command
```

The first command must be preceded by a "?"
Commands can be concatenated using the character "&"
Commands can be specified in upper case, lower case or mixed case

Example: if you want to switch to OFF the Power Outlet #1, type in:
<http://192.168.100.201/hidden.htm?M0:01=OFF>

Your Web browser will now display:

```
Hidden Page
21 Dec 2010 02:42:08
Version: 2.1.0.0
M0:01=Off
```

5. APPENDIX

5.1. Ping and Scan Methods

Power Switch has two methods to check whether an IP equipment (PC, server, router, Webcam...) is still alive:

Address Pinging:

The first method uses the well-known Ping command whereby a request is sent to a specific IP address. The Ping command, which is an echo request, enables you to determine through an ICMP protocol (Internet Control Message Protocol) if an IP device is available on the network. If the system reacts to this request, Power Switch knows that the TCP/IP connection is established. If the system does not react to one or several requests, Power Switch can automatically switch the device off and after a specified delay switch it again on (Reboot function).

Port Scanning:

The second method uses the Port Scan command to test a specific TCP/IP port. In other words, this command allows you to find out if a specific protocol is available on a server (for example HTTP, FTP, Telnet, POP...). Power Switch simply tries to connect to a specific server port. If the connection is possible, Power Switch knows that a server program is running there. If the connection is not possible, Power Switch can automatically switch the device off and after a specified delay switch it again on (Reboot function).

- **The Supervision function works only if the Power Switch is connected to the LAN.**
- **The Ping and Scan functions can be used separately or together.**
- **The network route between Power Switch and the IP device you wish to supervise should be as direct as possible, so do not use unnecessary routers and complex wiring between them. A problem on a router or the wiring could reboot the IP device to supervise.**
- **Execute several Pings and/or Scans before running the Reboot function. It could be possible that the IP device doesn't respond although it is still working.**
- **Choose a realistic supervision cycle. One second is possible, however it's not necessary to overload the network with Ping and Scan requests.**

Recommended values:

- Interval between Requests: 10 sec or more
- Number of unsuccessful Requests before Reboot: 3 or more
- Delay before Reboot: 10 sec or more
- Delay before restarting monitoring after Reboot: 120 sec or more



5.2. Technical Data

Network standards:

IEEE 802.3, 10 / 100 BASE-T

Network protocols:

TCP/IP, HTTP

Network connection:

RJ-45 connector for STP CAT5

Max. network cable length 100 meters

Serial connection:

RS232, SUB-D 9 female

Operating temperature:

0°C to +40°C

Operating humidity:

10% to 80% RH (not condensing)

Dimensions (LxDxH):

185 x 103 x 43 mm

Weight:

1 kg

Approvals:

CE, EN 60950-1, EN 55022, EN 55024

5.3. Commonly used Ports

TCP 80: This port is used for http connections.

UDP 123: This port is used to allow time synchronization over NTP (Network Time Protocol).

UDP 161: This port is used for SNMP Requests.

UDP 162: This port is used for SNMP Traps.

UDP 514: This port is used to deliver Syslog messages.

5.4. Syslog Messages: Severity Level Definitions

The Emergency level is the most severe type of message generated by Power Switch and the Debug severity level is the least severe one.

Severity Level 0, Emergency:

The following messages appear at severity 0:

- Continuous error!

Severity Level 1, Alert:

The following messages appear at severity 1:

- Settings have been reinitialized through the serial connection
- Power Switch does not respond

Severity Level 2, Critical:

The following messages appear at severity 2:

- "file" config corrupted: restoring default values

Severity Level 3, Error:

Power Switch doesn't generate Severity Level 3.

Severity Level 4, Warning:

The following messages appear at severity 4:

- Settings have been changed through the serial connection
- Settings have been changed through the network by User "name"

Severity Level 5, Notice:

The following messages appear at severity 5:

- System has been restarted through the serial connection
- Power Supply restored
- Rule (number) : Outlet (number) has been switched ON

Severity Level 6, Informational:

The following messages appear at severity 6:

- System has been started
- Date & Time have been synchronized to a Network Time Server
- User "name" : Outlet (number) has been switched ON
- Session opened by user "name"

Severity Level 7, Debug:

Power Switch doesn't generate Severity Level 7.